



Touch Key Programing: Uno/Duo

1. Turn the ignition key of the motorcycle off.
2. Touch one of the original touch keys to the touch pad to disarm the system. (The LED will light green)
3. Touch the new key to the pad within 5 seconds. (Note! You will hear a number of tones – this is the number of keys programmed into the unit) The key is now programmed.

NOTE!

General

If you or your customer have only one touch key, a replacement should be purchased immediately.

Duo Systems

If you or your customer has lost both touch keys it is not possible to code in a new touch key. The immobiliser, or Duo, circuit board must be returned to Datatool (UK) Ltd for re-programming. A nominal fee is made for this service.

Uno Systems

If you or your customer have lost both touch keys it is not possible to code in a new touch key. The Uno is a sealed unit and must be removed from the motorcycle and scrapped.